@Home S-class to V3 Gecko Pack Replacement.

Parts needed:


6600-536 Version 3 Gecko Pack
6600-537 Top side control
N001-65YU One pump inlay or
N001-80YU Two pump inlay (depending on the model)
01511-05 Small silicone tube
01782-1012 Cable MTA light harness

Please read instructions prior to performing this repair and make sure that all parts and accessories are available.



- V3 lower control is slightly shorter and longer than S-class, but heater is the same length with no need for any plumbing modifications.
- Version 3 Gecko lower controls do not use an external temperature sensor or pressure switch; these sensors are integrated on the heater.
- Jet pumps, circulation pump and ozone need to be connected directly to the pc-board.

 If the S-class lower control has a jumper/cable between L2 and Neutral, do not use it on V3 lower control.



OLD BOARD

PUMP #1 CONNECTOR (2 SPEEDS)

VOLTAGE	120∨ □	240V
GREEN / GROUND	P4	P4
WHITE / COM	P7	P18
BLACK / LOW SPEED	P14	P14
RED / HIGH SPEED	P101	P101

CIRC. PUMP CONNECTOR

GREEN / GROUND P47 WHITE / COM P49	_
WHITE / COAA	. •
WHITE / COM	236
BLACK / LINE P34	724

PUMP #2 CONNECTOR

VOLTAGE	240V
GREEN / GROUND	P6
WHITE / COM	P17
BLACK / LINE	P102

OZONE CONNECTOR

VOLTAGE	120V	
GREEN / GROUND	P5	
WHITE / COM	P8	
BLACK / LINE	P16	

NEW BOARD

	Wire color				
	DI 1	D 1	White		
Component	Black	Red	120V.	240V.	Green
Circulation pump	K1-P	-			
Ozone	K6-P	-			
Pump 1 Low speed	K2-P	-	Neutral	Line 2	Ground
Pump 1 Hi speed	-	K4-P	P36 to P45	P17 to P26	P6 to P14
Pump2 Hi	K3-P		P36 t0 P45		P6 10 P14
(1 speed only)					
Stereo pwr. supply	P55	-		-	


- 1) Determine and change the dark brown wire (P5) to line 2(P17) or Neutral (P14) depending on the power supplied.
- 2) Connect the light cable to P65. (Requires new light harness Part number 01782-1012)
- 4) Once all has been connected, reset the power to the spa. The Upper control will display L1 and needs to be configured depending on the equipment.
- Press the "+" or "-" button to select the level configuration according to the equipment options (ozone no ozone) and Voltage (120Vac–240Vac) Save by pressing the **Mode** "*" button.
- If the upper control does not display L1, change the level configuration by pressing and holding **Jet1** button for 30 seconds; change the level configuration and save with **Mode** "*" button.

Level Configuration table:


		Ozone and Circ. Pump		
System:	Models with:	No	Yes	
240Vac.	2 Jet pumps	L1	L6	
240Vac.	1 Jet pump	L4	L9	
120Vac.	1 Jet pump	L5	L10	

NEW BOARD

Wiring V3 pack.



OLD BOARD



WARNING: BEFORE OBTAINING ACCESS TO TERMINALS, ALL SUPPLY CIRCUITS MUST BE DISCONNECTED